

List of programmable functions for EasyCat, SmartCat & SmartCat Pro:

Disabled  
Left Click/Select  
Right Click /Menu  
Middle Click/Pan  
Click-Lock  
Double-Click  
Slow Mode  
Horizontal Only  
Vertical Only  
Insert  
Delete  
Home  
End  
Enter  
PageUp  
PageDown  
Tab  
Help  
Context Help  
Cut to Clipboard  
Copy to Clipboard  
Paste from Clipboard  
Undo (Alt-Backspace)  
Close Application  
Maximize Window  
Minimize Window  
Restore Window  
Minimize All Windows  
Restore Minimized Windows  
Start Menu  
Run  
Window Center  
Windows Explorer  
Default Web Browser  
Default Media  
Default Email  
Create New Link