

Palm Supports?

Yes

No

Tenting?

Tenting?

Yes

No

Yes

No

More than 15°?

More than 15°?

Yes

No

Yes

No



AC806PS

Keyboard Only



AC740

AC820

AC740

AC730

20" - 90" (20" cable req.)

5' / 10' / 15'

20" - 90" (20" cable req.)

5' / 10' / 15'

*Keyboard not included